

How to Read a Meter








If there is ONE stationary zero, Do Not Read LAST TWO moveable digits.

If there are TWO stationary zeroes, Do Not Read LAST moveable digit.

What the Numbers Mean







If there are THREE stationary zeroes, Read ALL moveable digits.

What the Numbers Mean



LOO Millions LOO Thousands Hundreds Ones